Application & Care Instructions

BEFORE YOU START...

Newly painted walls need 4 weeks to outgas before our products are applied.

Avoid rubbing the product or exposing to solvents or water.

These decals are removable from the wall but may be tricky to relocate with the same, perfect alignment.

- Scratch the clear layer on top with your nails, don't worry if it has "waves", it will still pick up the decals below.
- Cut between parts of the design to make it easier to place in sections. Text can be arranged as you like. Use a "level" or a friend to tell you if it is straight. You will have one chance to place your designs.
- 3. Peel the clear top layer back, make sure the decals stick to the top layer. Slide the clear layer back on itself to aid this.
- 4. Now place the clear layer on the wall. Rub it to the wall then peel back the clear layer leaving just the designs on the wall.

△ WARNING



